

Battery Care and Trouble Shooting, Charging Instruction



Storage:

- Batteries should be stored at temperatures between 5°C and 35°C in a clean dry and ventilated room.
- Batteries should avoid contact with corrosive substances, should stay away from fire and heat.

Care Instructions:

- Do not disassemble the battery - There is a protective mechanism and protection circuit to avoid danger inside the battery. Improper disassembly will cause the battery to heat, smoke, or catch fire.
- Avoid using a battery near a heat source. Overheating will cause the battery to generate heat, smoke, or catch fire. Do not expose a battery to heat or fire, avoid storage in direct sunlight. Do not expose a battery to temperatures above 35°C.
- Do not dispose a battery in water. It will cause the battery to heat, smoke, or catch fire
- Only charge a battery under normal conditions with supplied charger to avoid damage to the battery. Follow the instructions below on a guide to charge.
- Do not use non-dedicated charger to the battery as it creates the risk of damage to the battery.
- Avoid exposing the battery to excessive shock or vibration.
- It is prohibited to use any tools to damage or tamper with a battery. Hammering or other mechanical methods damaging the battery will most likely result in the battery heating, smoking or burning.
- Avoid any direct contact with a leaking battery. Do not touch any fluids. Check and follow your applicable regulations on dispose of a leaking battery pack.
- In case of eye contact with fluid, do not rub eyes. Immediately flush eyes thoroughly with water for at least 15 minutes, lifting upper and lower lids, until no evidence of the fluid remains. Seek medical attention immediately.
- Seek medical advice immediately if a cell or battery has been swallowed.
- Do not short-circuit a battery. Do not store or transport the battery together with metal.
- Do not store batteries in a box or drawer where they may short-circuit each other or be short-circuited by conductive materials. If the battery is shorted it will cause damage and quite possibly cause the battery to heat, smoke, or catch fire.
- Please ensure that each recliner chair which is operated by a Battery Pack:
 - (a) is not opened and closed in rapid succession. Doing so is likely to overheat the Battery Pack and cause it to fail; and
 - (b) has its own Battery Pack installed. Each recliner must have its own battery pack.
 The use of splitter cables to operate two or more recliner chairs is likely to overheat the Battery Pack and cause it to fail.

Trouble shooting:

If you experience any of the issues described below, please take the steps outlined for each issue before contacting the Adriatic service department or making a claim under this warranty.

1. You charged the battery overnight but the Battery Pack is not operating:
 - (a) Please check whether the LED light on the Battery Pack is green, which indicates that the Battery Pack should be operating normally.
 - (b) If there is no green light or the LED light is not working, please check the connection between the transformer and the battery. Press firmly onto the terminal to ensure an adequate connection.
2. Battery Pack has discharged very quickly:
 - (a) Please do not use or charge the battery for 2 hours and then charge the Battery Pack for 6-8 hours.
3. Battery is beeping:
 - (a) Please connect the charger and charge the Battery Pack for 6-8 hours. A protection circuit in the Battery Pack will sound an alarm for 30 seconds to indicate that the battery needs to be charged.

Charging:

<p>To Charge: Prepare one charger cable, one battery pack, one AC power cable and one socket.</p>	<p>Connection Order: Connect the AC power cable with the AC terminal of charger cable. Input line of charger cable is connected to input socket of battery pack, and output line of cable with the output socket of battery.</p>	<p>To Start Charging: When the AC power cable is plugged into the power socket the battery pack lights up red. Charging starts.</p>	<p>To Stop Charging: When the light turns green, it indicates that the battery pack is fully charged. At this time, AC power cable must be pulled out from the power socket to stop charging.</p>

Lithium Ion Battery Pack Adriatic Warranty Information



Lithium Ion Battery Packs - Adriatic Warranty information

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Further details of your consumer rights may be found at www.consumerlaw.gov.au.

Warranty against defects

The benefits given to you by this warranty are in addition to other rights and remedies which you may have under law, including under the Australian Consumer Law. Should your Battery Pack be defective, you may choose to make a claim under the Australian Consumer Law or this Adriatic Warranty Against Defects.

Warranty period

Unless otherwise specified in writing by Adriatic (e.g. in a Sales Order) and subject to the other terms of this warranty, Adriatic warrants that any Lithium Ion Battery Pack supplied by Adriatic to you (the **Battery Pack**) will be free from manufacturing defects for a period of 12 months from the date of purchase (the **Warranty Period**). To be entitled to claim under this warranty, the defect in the Battery Pack must appear within the Warranty Period.

Exclusions (subject to the Australian Consumer Law)

4. To the maximum extent permitted by law, and subject to the Australian Consumer Law, Adriatic Furniture Imports Pty. Ltd is not liable under this warranty for or in respect of:
 - 4.1 any defect that is unrelated to the condition of the Battery Pack at the time it was supplied to you, including damage or faults caused by: improper transportation, storage or installation of the Battery Pack after the date of purchase; modification, alteration, disassembly or attempted repair of the Battery Pack by a person other than, or authorised by, Adriatic; external influences during the life of the Battery Pack, such as fire, water damage or power surges in a premises;
 - 4.2 the failure of the Battery Pack to operate on a single charge for any length of time before it requires recharging. Because of many variables, such as the nature and use of the recliner in which the Battery Pack is installed, Adriatic is unable to guarantee that the Battery Pack will operate for any particular period before it requires recharging;
 - 4.3 minor issues in the Battery Pack which do not substantially interfere with the ordinary use of the Battery Pack for powering recliner movements.
 - 4.4 any damage or faults caused by the failure to use the Battery Pack in accordance with the Care instructions or failure to take reasonable steps to prevent the problem, or abnormal use of the Battery Pack; and
 - 4.5 any loss or damage suffered by you or any other person in connection with the goods which is not expressly covered by this warranty including, but not limited to, indirect and consequential loss (subject to any other rights you may have at law).
5. This warranty is not transferable. It is limited to the original purchaser specified in the original Sales Order.
6. This warranty only applies to the Battery Pack if it is used for normal domestic purposes and excludes Battery Packs used for commercial purposes.

How to make a claim under this warranty

7. To claim under this warranty, you must:
 1. cease using the Battery Pack immediately after the defect appears;
 2. notify Adriatic within 7 calendar days after the defect appears; and
 3. provide Adriatic with a copy of the original Sales Order Form or tax invoice.
8. To make a claim, you can lodge a service ticket on our website at : www.adriatic.com.au/service-request/ or telephone the service department of Adriatic on 03 9350 1000
9. Once a claim has been lodged with our service department, Adriatic will assess your claim and respond within 10 business days.
10. The Purchaser must bear the expense of making the claim, and the cost of all freight, house calls, labour and other items. These will be charged to the Purchaser at standard Adriatic rates. (If NOT a manufacturing fault and within the warranty period as stated above)

Remedies

11. If the Battery Pack is determined by Adriatic to have a manufacturing defect, Adriatic will, at the discretion of Adriatic, choose whether to replace the Battery Pack with a new Battery Pack or provide you with a refund equal to the purchase price of the Battery Pack.
12. Any available remedy under this warranty relates to the Battery Pack only, and not any other Battery Pack or item (including a recliner in which the Battery Pack was installed).